




| | |
|----------------------|--|
| Model | E60F - Wood Cooker |
| Flue Exit | ABOVE RIGHT |
| Type Of Cookingplate | CAST-IRON |
| Top Plate | SQUARED H=40 mm backsplash h50x20mm |
| Finishing | STANDARD |
| Colour | BLUE |
| Doors | S. STEEL DOORS ECO |
| Handles | S.STEEL HANDLES D3 |
| Base | S. STEEL BASE H=30 mm |

| | |
|-------------------|---------------|
| L) Width: | 600 mm |
| P) Depth: | 600 mm |
| A) Height: | 860 mm |

| | |
|---------------|--------|
| a) Top plate: | 40 mm |
| b) Body: | 790 mm |
| c) Plinth: | 30 mm |



write here the code to modify the configuration
20213037493

